



PAGE 1 (2)	SPARE PARTS LIST FOR IRO 5020.08.XX/7020.08.XX LASER.  THE POSITION NUMBERS CORRESPOND TO REF. NO. 20-8910-0811-03/0248 EXPLODED VIEW.	REF. NO. 20-8920- 0811-12 / 0248	
------------	--	---	---

VALID FROM SERIAL NOS. 98110944

<b>POS</b>	<b>PART NO/</b>	<b>DESCRIPTION</b>
1	900.1011	NUT
2	900.0035	SCREW
4	120.0055.000E	MOUNT INCL. POS 1,2
5	900.0081	SCREW
6	120.0054.000E	LOWER COVER
7	120.4017.003D	MOTOR COMPL.
8	900.0344	SCREW
9	900.4042	BEARING
10	900.6101	EYELET
11	120.4019	S/Z BUTTON
12	900.9104	O-RING
13	120.4021	MAGNET
14	120.4020	ON/OFF SWITCH
15	820.0389.1750	CABLE 175cm
15	820.0389.3000	CABLE 300cm
15	820.0389.5500	CABLE 550cm
16	900.9162	CIRCLIP
17	900.2089	WASHER
18	120.4016.002E	COVER
19	25.0259	INDICATOR COVER
20	900.0081	SCREW
21	900.0145	SCREW
22	900.0117	SCREW
23	120.0335.000E	NOSE INCL. EYELET
24	900.6104	EYELET
25	120.4007.011	SENSOR ASSEMBLY WITH YARN BREAK SENSOR
25	120.4007.012	SENSOR ASSEMBLY WITHOUT YARN BREAK SENSOR
26	900.0142	SCREW
27	120.9039.02020	MOTOR CIRCUIT BOARD
28	900.0307	SCREW
29	900.9054	O-RING
30	900.5271	GROMMET
31	120.0023	SCREW
32	900.9176	KEY
33	900.6134	EYELET
34	900.4043	BEARING
35	900.9021	CIRCLIP
36	900.9029	CIRCLIP
37	120.4015	WINDING DISC COMPL.
38	900.6135	EYELET
39	900.0386	SCREW
40	900.9156	O-RING
41	900.0409	SCREW
42	120.4025	MAGNET RING
43	25.0391	COUNTERWEIGHT
44	900.2126	SHIM
45	25.0450	INCLINED HUB
45	25.0436	INCLINED HUB COMPL. INCL. POS.43,44
46	900.4044	BEARING
46	900.4044	BEARING
47	120.0044	SPACER
48	120.0031	TUMBLE CYLINDER WITH BEARINGS
49	25.0406	WASHER
50	120.0042	NUT
51	820.0339	SEALING BODY
52	900.4042	BEARING
53	25.0467	SPOOLBODY WITH BEARINGS
54	25.0435	YARN SENSOR KIT WITH YARN BREAK SENSOR
54	25.0435.001	YARN SENSOR KIT WITHOUT YARN BREAK SENSOR
56	120.0021	SPACER
57	25.0470	WASHER PACKAGE AND SCREW

PAGE 2 (2)	SPARE PARTS LIST FOR IRO 5020.08.XX/7020.08.XX LASER.  THE POSITION NUMBERS CORRESPOND TO REF. NO. 20-8910-0811-03/0248 EXPLODED VIEW.	REF. NO. 20-8920- 0811-12 / 0248	
------------	--	---	---

VALID FROM SERIAL NOS. 98110944

<u>POS</u>	<u>PART NO/</u>	<u>DESCRIPTION</u>
59	820.0026	COVER
60	20.5040	BRUSH HOLDER
61	820.0360.001	BRUSH RING SOFT
61	820.0360.002	BRUSH RING MEDIUM
61	820.0360.003	BRUSH RING STIFF
61	820.0360.004	BRUSH RING VERY STIFF
62	25.0475	HOLDER
63	107.5253	CONE INCL. PARTS 64,65,66
64	107.5214	TENSIONER DISC
65	807.5215	COLLAR
66	900.0424	SCREW
67	25.0409	SCREW
68	107.5284.002	TENSIONER DISC
69	107.5192.001	SPRING (MEDIUM)
69	107.5192.002	SPRING (STIFF)
69	107.5192.004	SPRING (SOFT)
70	107.5200.000E	NOSE COMPL.
71	900.6101	EYELET
72	120.0348.0008	TENSIONER COMPL.
73	40.0121.104	FLEX BRAKE EXTRA SOFT (WHITE)
73	40.0121.101	FLEX BRAKE SOFT (BLACK)
73	40.0121.102	FLEX BRAKE MEDIUM (BLUE)
73	40.0121.105	FLEX BRAKE STIFF (RED)
74	25.0553	GYRO RING
75	27.0307.003	PUSH FLEX SOFT
75	27.0307.015	PUSH FLEX MEDIUM
75	27.0307.025	PUSH FLEX STIFF
75	27.0310.023	PUSH FLEX VERY STIFF
76	25.0685	GYRO RING
77	20.0291.002	NOSE PART, PUSHFLEX
78	24.0174	THREADING NEEDLE
79	807.4447	NEEDLE HOLDER
100	25.0397.000E	BOX
101	20.5024.008	TRANSFORMER 200/220,346,380,400/415
101	20.5024.108	TRANSFORMER 440/460,480/500,550/575/600
101	20.5024.308	TRANSFORMER 260
102	900.5597	GROMMET
103	900.5536	GROMMET
104	900.5444	CABLE CLAMP
105	900.5307	MAIN SWITCH
106	900.5324	NUT
107	25.0628	METAL FOOT
108	900.1002	NUT
109	900.5595	FUSE 2A SLOW BLOW
109	900.5716	FUSE 4A SLOW BLOW
110	820.0277.102	FUSE BOARD 2-COL.
110	820.0277.104	FUSE BOARD 4-COL.
110	820.0277.108	FUSE BOARD 8-COL.
110	820.0279.704	FUSE BOARD 4-COL. HIGH SIGNAL
110	820.0279.708	FUSE BOARD 8-COL. HIGH SIGNAL
110	820.0279.804	FUSE BOARD 4-COL. LOW SIGNAL
110	820.0279.808	FUSE BOARD 8-COL. LOW SIGNAL
111	120.0381.000E	COVER 2-4 COLOUR BOX
111	120.0382.000E	COVER 8 COLOUR BOX
112	25.0716	BAR
113	900.2008	WASHER
114	900.0497	SCREW
115	40.0265	CLAMP
116	900.0333	SCREW
117	900.9375	PLUG